

Ball Joint Separator

Scissor Type

- 1 - Ensure the threaded bar is well lubricated before use.
- 2 - Position tool on joint.
- 3 - Turn the thrust nut in a clockwise direction to apply tension to the ball joint.
- 4 - Strike the ball joint with a hammer to shock the joint loose. Several strikes may be necessary to loosen the joint sufficiently to be dismantled.

NOTE: DO NOT strike the tool with a hammer or other heavy object. Any tool returned showing signs of abuse will be exempt from any Warranty claim.

