
LASER®

Instructions




www.lasertools.co.uk

A complete engine timing kit designed to allow the timing to be set and checked on the 1.4 & 1.6 PSA/BMW engines found in the BMW, MINI and PSA ranges. Engine codes covered include N12, N13, N14, N16 & N18 for BMW & MINI and EP3, EP6 for Citroën/Peugeot. Includes the digital angle gauge (Inclinometer) recommended by PSA for checking the chain wear in-situ.

Components

NOTE: A, B, D components are EU Registered Design



Ref	Code	OEM Ref	Description
Α		0197-A1/A1Z, 0197-A11, 11 7 440, 11 9 551, 11 9 540	Exhaust Camshaft Alignment Tool
В		0197-A2, 11 9 551	Inlet Camshaft Alignment Tool
C			M10 Screw
D		0197-A3, 0197-031, 11 7 440, 11 9 540	Inlet Camshaft Alignment Tool
E	C785	0197-BZ, 11 9 590, 49 6 709, 2 299 362	Flywheel Timing Pin
F			M5 Screws x6 off
G		0197-A1/AZ, 11 7 440, 11 9 540	Exhaust Camshaft Alignment Tool Adapter
Н		All Cam Assemblies	Link Bar For A & B
1		0197-A2, 11 9 551	Inlet Camshaft Alignment Tool Adapter
J		0197-A31, 11 7 440	Inlet Camshaft Alignment Tool Adapter
K		0197-A11, 11 9 551, 11 9 440	Exhaust Camshaft Alignment Tool Adapter
L		0197-A3, 11 9 540	Inlet Camshaft Alignment Tool Adapter
М	C784	G-1376-A	Digital Inclinometer
N	C786	0197-M, 11 9 340	Dummy Timing Chain Tensioner
0	C787	E1.100	Angle Bracket

Items identified in **GREY SHADED TABLE CELLS** are built up of a number of components. To identify which components are required for each kit please refer to the cross reference below.

Camshaft Locking	amshaft Locking Cross Reference - PSA				
OEM Numbers	Component Code	Items			
0197-A1/A1Z	C788 - Exhaust Camshaft Alignment Tool Assembly	A+G			
0197-A11	C789 - Exhaust Camshaft Alignment Tool AAssembly	A+K			
0197-A2	C790 – Inlet Camshaft Alignment Tool Assembly	B+I			
0197-A3	C791 – Inlet Camshaft Alignment Tool Assembly	D+L			
0197-A31	C792 - Inlet Camshaft Alighment Tool Assembly	D+J			
Camshaft Locking	Cross Reference - BMW				
11 7 440	C793 – Camshaft Alignment Tool Assembly	A+K+H+D+J			
11 9 551	C794 - Camshaft Alignment Tool Assembly	A+K+H+B+I			
11 9 540	C795 - Camshaft Alignment Tool Assembly	A+G+H+D+L			

Applications

Make, Mo	odel, Year		Engine Codes	
Citroen	Berlingo III	2009 - 2018	1,4	5FU (EP6CDTX)
	C3, C3 Picasso	2009 - 2015	N12 B14A	5FV (EP6CDT)
	C4, C4 Picasso	2008 - 2019	1,4 Vti	5FX (EP6DT)
	C5 III	2009 - 2015	8FN (EP3C) 8FP (EP3C)	5GM (EP6FDTX) 5GR (EP6FDTX)
	DS3, DS3 Cabrio	2009 - 2017		
	DS4	2011 - 2015	8FR (EP3C)	5GT (EP6FDTX)
	DS5	2012 - 2015	8FS (EP3) 1.6	5GW (EP6FDT) 5GY (EP6FDT)
Peugeot	207, 207 CC	2006 - 2016	- 1,6 N13 B16A	5GY (EP6FDTM)
reugeot	208	2012 - 2019	N14 B16A	5GZ (EP6FDT)
	308, 308CC	2007 - 2019	N14 B16C	EP6CDT (5FA)
	508	2011 - 2018	N16 B16A	EP6CDT (5FE)
	2008	2013 - 2017	N18 B16A	EP6CDT (5FM)
	3008	2009 - on	N18 B16C	EP6CDT (5FN)
	5008	2009 - on	1,6 Vti 5FK (EP6CB) 5FL (EP6C) 5FP (EP6) 5FS (EP6C) 5FW (EP6)	EP6CDT (5FV)
	Partner	2009 - 2018		EP6CDTR (5FG)
	BCZ	2010 - 2016		EP6CDTX (5FU)
	3	2015 - 2019		EP6DT (5FT)
os	4	2015 - 2019		EP6DT (5FX)
	5	2015 - 2018		EP6DTE (5FR)
	7 Crossback	2013 - 2018 2017 - on	EP6 (5FW)	EP6DTS (5FY)
	1 Series	2017 - 011	EP6C (5FH)	EP6FDT (5GW)
BMW			EP6C (5FK)	EP6FDT (5GZ)
	3 Series	2012 - 2015	EP6C (5FS) 1,6 THP	EP6FDTM (5GY)
MINI	Mini	2006 - 2015	5FD (EP6DTS)	EP6FDTR (5GN) EP6FDTR (5GP)
	Clubman	2007 - 2014	5FD (EP6DTS) 5FE (EP6CDTM)	EP6FDTK (5GP)
	Countryman	2010 - 2017	5FE (EP6CDTM) EP6FDTX (SGR) 5FF (EP6CDTS) EP6FDTX (5GT) 5FM (EP6CDTM) 1,6 PureTech 5FN (EP6CDT) 5GY (EP6FADTXD) 5FR (EP6DTE) 5GF (EP6FADTX)	, ,
	Coupe	2011 - 2015		, ,
	Roadster	2012 - 2015		
	Paceman	2013 - 2017		
			5FT (EP6DT)	5GG (EP6FADTX)

Always refer to the website for most up to date applications: www.lasertools.co.uk/product/6814

Instructions

The following instructions are for guidance only. Please refer to OEM derived data such as the vehicle manufacturers' own data or Autodata.

The use of this engine timing tool kit is purely down to the user's discretion and The Tool Connection Ltd. cannot be held responsible for any damage caused whatsoever.



www.lasertools.co.uk

Introduction


The engine applications listed use two distinct camshaft positions. One engine style positions the camshafts level and the second positions the inlet camshaft noticeably higher than the exhaust camshaft.

While there are only two basic engine configurations there are many different mounting adaptor positions dependent on specific engine code detail. In order to identifying the correct assembly method of the camshaft locking tool for the engine being worked on it is important the OEM tool numbers are correctly identified.


Use the OEM tool numbers with the Laser cross reference chart and drawings below to identify the tool configuration required.

Basic Component Use

- Lock the Engine with all pistons at equal heights, use a suitable rod or measurement tool to ensure piston 3 and 4 are level. Insert the flywheel timing pin (E).
- Ensure the camshafts are correctly aligned with their alignment flats positioned as shown.




• Use components (M) digital inclinometer and (O) to check the chain stretch in accordance with OEM specification (PSA). Place (M) and (O) on the cylinder head as shown and zero M. move components (M) and (O) so that the angle of the side flat of the camshaft is displayed on (M) as shown. Compare to OEM specification.




- Lock both camshafts with component A + B or A + D with appropriate alignment adaptors as dictated by the OEM part numbers required.
- . NB: Mount the camshaft locking components with the link bar (H) facing the Gear box end of the engine.


For BMW N13 and N18 Engines assemble the camshaft locking components as shown.



For BMW N14 engines assemble the camshaft locking components as shown.




For BMW N12 engines assemble the camshaft locking components as shown.




www.lasertools.co.uk www.lasertools.co.uk For Peugeot Citroen assemble the camshaft tools according to the OEM tool numbers required as shown here:

• NB: Mount the camshaft locking components with the link bar (H) facing the Gear box end of




www.lasertools.co.uk



Basic Use of Locking Components

Assembled camshaft locking tool



Safety Warnings - please read

- If the engine has been identified as an Interference engine, damage to the engine will occur if the timing belt has been damaged. A compression check of all the cylinders should be taken before the cylinder head (s) are removed.
- Do not turn crankshaft or camshaft when the timing belt/chain has been removed.
- To make turning the engine easier, remove the spark plugs/glow plugs or injectors.
- · Observe all tightening torques.
- Do not turn the engine using the camshaft or any other sprocket.
- Disconnect the battery earth lead (check Radio code is available).

- Do not use cleaning fluids on belts, sprockets or rollers.
- Some toothed timing belts are not interchangeable. Check the replacement belt has the correct tooth profile.
- Always mark the belt with the direction of running before removal.
- · Do not lever or force the belt onto its sprockets.
- Do not use timing pins to lock the engine when slackening or tightening the crankshaft pulley bolts.
- ALWAYS REFER TO A REPUTABLE MANUFACTURERS WORKSHOP MANUAL.



Safety First. Be Protected.

Our products are designed to be used correctly and with care for the purpose for which they are intended. No liability is accepted by the Tool Connection for incorrect use of any of our products, and the Tool Connection cannot be held responsible for any damage to personnel, property or equipment when using the tools. Incorrect use will also invalidate the warranty.

If applicable, the applications database and any instructional information provided has been designed to offer general guidance for a particular tool's use and while all attention is given to the accuracy of the data no project should be attempted without referring first to the manufacturer's technical documentation (workshop or instruction manual) or the use of a recognised authority such as Autodata.

It is our policy to continually improve our products and thus we reserve the right to alter specifications and components without prior notice. It is the responsibility of the user to ensure the suitability of the tools and information prior to their use.



6814_Instructions_V8



O TOOL

www.lasertools.co.uk

Distributed by The Tool Connection Ltd

Kineton Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: +44 (0) 1926 818186. Normal wear and tear are excluded as are consumable items and abuse.

