



LASER®

Part No. 4807

Oliepeilstok - Audi



When you have finished with
this bottle please recycle it

www.lasertools.co.uk



Distributed by The Tool Connection Ltd

Kinton Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: +44 (0) 1926 818186. Normal wear and tear are excluded as are consumable items and abuse.

www.lasertools.co.uk

www.lasertools.co.uk

instructies voor gebruik

Voorzorgen en voorbereiding:

- Controleer of het voertuig op een vlakke ondergrond staat
- De olie moet tot een minimumtemperatuur van 60 graden C/140 graden F zijn
- Schakel de motor uit en wacht 5 minuten tot het oliepeil tot rust is gekomen

Instelling 4807

Stel de instelring in volgens de hieronder getoonde maat voor de voertuiglijst hieronder en draai de borging vast. Hierdoor wordt de lengte van de peilstok ten opzichte van de motor ingesteld.

Steek de 4870 in de peilstokbuis in het voertuig tot de instelring de bovenkant van de buis raakt.

Verwijder de peilstok en lees het peil af op de onderste schaal.

Jaar	Motortype	Ringinstelling	Minimum op de onderste schaal	Maximum op de onderste schaal
vanaf 2009	2.0 TFSi	39	0	24
vanaf 2009	3.2 FSi	123	0	13
vanaf 2009	3.0 Supercharged	123	0	13
vanaf 2009	4.2 FSi	175	0	23
vanaf 2009	2.0 TDi CR	46	0	24

