



LASER®

Part No. 4807

Ölmessstab - Audi



5 018341 048075 >



When you have finished with
this batter please recycle it

www.lasertools.co.uk



Distributed by The Tool Connection Ltd
Kineton Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: +44 (0) 1926 818186. Normal wear and tear are excluded as are consumable items and abuse.

www.lasertools.co.uk

www.lasertools.co.uk

Hinweise zur Verwendung

Vorsichtsmaßnahmen und Vorbereitung:

- Stellen Sie sicher, dass das Fahrzeug eben steht
- Das Öl muss auf einer Mindesttemperatur von 60 Grad C/140 Grad F sein
- Schalten Sie den Motor aus und warten Sie 5 Minuten, damit das Öl zurücklaufen kann.

Einstellung 4807

Setzen Sie den Stellring auf die unten gezeigte Messung für die unten stehende Fahrzeugliste auf und ziehen Sie die Arretierung fest. Dies stellt die Länge des Ölmessstabs auf den Motor ein.

Setzen Sie 4870 in das Rohr des Ölmessstabs am Fahrzeug ein, bis der Stellring die Oberseite des Rohrs berührt.

Entfernen Sie den Ölmessstab und lesen Sie den Füllstand an der unteren Skala ab.

Jahr	Motortyp	Ringe instellung	Untere Skala Minimum	Untere Skala Maximum
ab 2009	2.0 TFSI	39	0	24
ab 2009	3.2 FSi	123	0	13
ab 2009	3.0 Aufgeladen	123	0	13
ab 2009	4.2 FSi	175	0	23
ab 2009	2.0 TDI CR	46	0	24