

Subframe Alignment Pins - for Ford

Part of a range of vehicle specific tools for the removal and fitting of bushes and ball joints without having to remove suspension legs, subframes, wishbones and trailing arms etc from the vehicle. Designed to be used in-situ, although can also be used in a workshop press if circumstances require.



Additional Information

- Designed to quickly and simply align the subframe to ensure the axle, suspension and steering components remain correctly aligned on the vehicle.
- Applications include: Ford C-Max, Cougar, Escort, Fiesta, Focus, Fusion, Galaxy, Kuga, Mondeo, Orion, Puma, S-Max, Tourneo Connect, Transit, Transit Connect and Transit Custom.
- Equivalent to Ford OEM 205-316-A.
- Use in accordance with OEM instructions.
-

<http://lasertools.co.uk/product/7467>

