

Front Suspension Bush Tool - for VW T5, T6

Part of a range of vehicle specific tools, for the removal and fitting of bushes and ball joints, without having to remove suspension legs, subframes, wishbones, trailing arms etc from the vehicle. Designed to be used in-situ, although many can also be used in a workshop press if circumstances require.



Additional Information

- Applications includes: VW T5, T6 vans (from 2003), including Transporter, Caravelle & Multivan.
- Specifically for OEM bush numbers 7H0 407 183 & 7H0 407 182 and aftermarket direct equivalents.
- Patented design ensures both bushes are correctly aligned to each other.
- Laser tools advise replacement of both bushes on both sides at the same time.
-

<http://lasertools.co.uk/product/7796>

Suitable for VW T5 models:

