

## Rear Axle Carrier (Sub-frame) Bush Tool – for BMW X5 &

Designed to remove and fit the 4 rear sub-frame bushes found on the BMW X5 (E53 chassis). Can also be used on the L322 Range Rovers that utilise the same BMW sub-frame assemblies.



### Additional Information

- Applications include: BMW X5 (E53 chassis 1999 - 2006) & Range Rover L322 (2001 - 2011).
- Used to extract and insert the sub-frame (differential carrier) to body bushes without dropping the sub-frame from the vehicle.
- Always warm the frame around the bush with a hot air gun (not flame). Use with hand tools only.
- Lubricate the new bush to aid insertion. Use in accordance with OEM instructions.
- BMW OEM bush number 33 31 6 770 454.

<http://lasertools.co.uk/product/8739>

