

## CV Boot Clamp Pliers 260mm

260mm long CV boot clamp pliers for use on earless clamps.



### Additional Information

- Applications: Earless clamps fitted to axle boots on Audi, BMW, Chrysler, Ford, GM, Honda, Mazda, Mercedes-Benz, Nissan, Opel, Porsche, VAG.
- Spring loaded action.
- Also suitable for thermoplastic axle boots.
- Dipped handles for comfort.
- 

<http://lasertools.co.uk/product/6737>



