

## CV Boot Clamp Pliers 3/8"D

CV boot band pliers 3/8"D torque drive for VAG, Vauxhall /Opel, Ford and others



### Additional Information

- Applications: VAG, Vauxhall/Opel, Ford and others
- With 3/8" torque drive
- Two way jaws for hard to reach areas
- For fitting stainless steel bands on drive shafts where a torque setting is specified
- Can be used by hand or with a flexi bar. Suitable for use with Laser torque wrench - Part No. 3451

<http://lasertools.co.uk/product/7316>



