




H1	Part No.	Description
1	H1-01	Body Frame
2	H1-02	Draw Bar Lead
3	H1-03	Sleeve Seat
4	H1-04	Jaw Case
5	H1-04-1	Jaws
6	H1-04-2	Jaw Pusher
7	H1-04-3	Press Spring
8	H1-04-4	Spring Screw
9	H1-05	Nose Piece
10	H1-06	Lever
11	H1-07	Body Pin
12	H1-08	Connecting Bar

H1	Part No.	Description
13	H1-09	Bar Pin
14	H1-10	E-6 Ring
15	H1-11	Balancing Bar
16	H1-12	Screw
17	H1-13	Handle
18	H1-14	Handle Pin
19	H1-15	Handle Lock
20	H1-16	Handle Lock Spring
21	H1-17	Lock Spring Stopper
22	H1-18	Plastic Grip
23	H1-19	Spanner 17 and 12
24	H1-20	Spanner 19 and 15

H2	Part No.	Description
25	H2-03	Sleeve Seat-1865
26	H2-04	Draw Bar
27	H2-05	Screw of Mouth Part
28	H2-05-1	Nut of Mouth Part
29	H2-21	Spanner 8.5 and 5.5

