

5166

# LASER<sup>®</sup>

## Flywheel Locking Pins BMW 2.0 | 3.0 Diesel Engines

### Instructions



When you have finished with  
this leaflet please recycle it



5 018341 051662 >

[www.lasertools.co.uk](http://www.lasertools.co.uk)

### Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.

[www.lasertools.co.uk](http://www.lasertools.co.uk)

**TOOL  
CONNECTION**

The Complete Connection

Distributed by The Tool Connection Ltd

Kineton Road, Southam, Warwickshire CV47 0DR

T +44 (0) 1926 815000 F +44 (0) 1926 815888

info@toolconnection.co.uk [www.toolconnection.co.uk](http://www.toolconnection.co.uk)

[www.lasertools.co.uk](http://www.lasertools.co.uk)

## Flywheel Locking Pins

These 2 Flywheel Locking Pins are required to extend the coverage of the Laser Part No 3577

The exact pin required is not always identified by Autodata and other technical sources therefore both pins are required to give the full choice.

Which pin is required is dependent on transmission type and there are many different types of transmission.

Component Code	OEM Ref	Description
C526	11 5 180	Flywheel Locking Tool
C527	11 6 080	Flywheel Locking Tool

## Applications:

Make	Engine	Year	Type
1 series	20 4D 4 = 2.0lt 4 cylinder diesel	2003-07	E81   82 87   88
3 series	20 4D 4 = 2.0lt 4 cylinder diesel	2003-06	E46
5 series	20 4D 4 = 2.0lt 4 cylinder diesel	2003-09	E60   61
3 series	30 6D 2   3   4   5 = 3.0lt 6 cylinder diesel	2003-11	E46   90   91 92   93
5 series	30 6D 2   3   4   5 = 3.0lt 6 cylinder diesel	2003-11	E60   61
7 series	30 6D 2   3   4   5 = 3.0lt 6 cylinder diesel	2002-05	E65   66
X3	30 6D 2   3   4   5 = 3.0lt 6 cylinder diesel	2003-10	E83
X5	30 6D 2   3   4   5 = 3.0lt 6 cylinder diesel	2003-10	E53   70
X6	30 6D 2   3   4   5 = 3.0lt 6 cylinder diesel	2008-10	E71   72