

Gear Puller Set

Automatic spring tensioned jaws, which make it simple to position the puller with one hand. Can be used in either two-leg or three-leg configuration.



Additional Information

- This gear puller can be changed to operate with 2 or 3 jaws.
- Internal or external pulling action 75 - 180mm.
- Simply unscrew the knurled screw cap to release spring and jaw cover, unhook the jaws and replace as necessary.
- Replace cover plate and tighten spring with knurled screw.
- Keep clean and well oiled between uses.

<http://lasertools.co.uk/product/3850>