



Diesel Injector Seal Puller

A specialised tool, used to assist the extraction of the copper washers used to seal diesel injectors where they enter the cylinder head.



Additional Information

- No moving parts to drop into the engine.
- Removes seals with ease.
- Slide hammer assists in extraction.
- Tip diameter: 4.5mm (min) to 13.2mm (max).
- Made in Sheffield.

<http://lasertools.co.uk/product/5450>

