

Tyre Valve Tool Set 3pc

Used to remove and replace leaking rubber body tyre valves without removing the tyre.



Additional Information

- Kit contains a valve hook tool, screw tool, and tapered tube. Used with Laser Part Nos. 4220 or 5436 valve core tool.
- The hook is used to remove the old valve body, the screw tool and tapered tube are used for fitting. Lubricate with tyre lube or similar.
- Ideal for replacing leaking valves on cars, vans, motorcycles etc.
- Ideal for use when it isn't straightforward to remove and refit tyres, such as those on motorcycles or agricultural vehicles.
- Not suitable for tyres with TPMS.

<http://lasertools.co.uk/product/5540>

Video available: <https://youtu.be/-8VngFqG8RI>

