

Shock Preload Adjusting Tool

Shock preload adjusting tool fits spring collars on motorcycles: 35mm to 75mm.



Additional Information

- Size range: 35mm-75mm.
- Helps to adjust the preload spring collars without damage.
- Hooked jaw for grip.
- Soft grip handle.
-

<http://lasertools.co.uk/product/6824>



