LASER®

Anti-Zap Protector 12/24V

Anti-zap protector 12 or 24v prevents damage to electrical systems whilst welding or jump starting.



Additional Information

- Prevents damage to electrical systems from voltage spikes during welding or jump starting.
- For use on 12 volt or 24 volt systems. Features heavy duty insulated clips.
- Polarity protected reverse connection warning.
- Designed to be fitted across the battery terminals to absorb unwanted power surges.
- LED indicators: Green light on = protection; Red light on = reverse connection. With no protection, an alarm will sound. CE, UKCA & RoHS compliant.

http://lasertools.co.uk/product/7824

Video available: https://youtu.be/aZB5YJhFg6k













