

## Axle Half-Shaft Puller - HGV

Designed to attach to the half shaft fixing bolts, behind the half shaft end cap, to allow the shaft to be extracted from the axle. The head of the puller force screw is shaped to allow the use of a copper mallet to shock particularly stubborn shafts to help release them.



### Additional Information

- Designed to pull the half shaft out of the axle without damage.
- Applications include: Eaton, Dana & Rockwell drive axles.
- Kit includes: stud adaptors, half shaft end cap lugs, force screw & puller bridge.
- Ensure force screw is lubricated with molybdenum disulphide grease prior to use.
- 

<http://lasertools.co.uk/product/9035>

