

## Airbag Release Tool - for Vauxhall/Opel

Allows safe removal of the airbag without risk of damage to other components.



### Additional Information

- Applications: Vauxhall/Opel Insignia & Astra (from 2008).
- Before removing the airbag always disconnect the vehicle battery and observe any recommended waiting times. Refer to manufacturers instruction.
- Lower the steering column to its lowest and rear most position to gain access to the release lever hole.
- Insert the tool as shown and release the airbag by levering the holding spring away.
- 

<http://lasertools.co.uk/product/6583>



