

## Crankshaft Trigger Wheel Installer - for JLR

Trigger wheel installer required to install the crankshaft position sensor ring on certain Land Rover engines and install trigger wheel to rear crankshaft on certain Jaguar models.



### Additional Information

- Land Rover applications: required to install the crankshaft position sensor ring on Discovery 3 & 4, Range Rover Sport when fitted with TDV6 engine (3 Powertrain).
- Jaguar applications: required to install the trigger wheel to the rear crankshaft on X200 S Type, X250 XF, X350 XJ & X351 XJ (300 powertrain).
- Equivalent to OEM 303-1130.
- Overall diameter: 123.5mm.
- Specifically requested to repair sensor wheel dropping off or cracking.

<http://lasertools.co.uk/product/6831>





**LASER**

6831

**Crankshaft Trigger Wheel Installer**  
Land Rover | Range Rover | Jaguar

**Land Rover Applications:** Required to install the crankshaft position sensor ring on Discovery 3/4, Range Rover Sport when fitted with TDV6 engine (3 Powertrain)

**Jaguar Applications:** Required to install the Trigger Wheel to the rear crankshaft on XJ220 S Type, X220 XE, X350 XJ and X351 XJ (300 Powertrain)

• Equivalent to OEM 800-1130

• Overall dimension: 125mm

• Specifically requested to repair sensor wheel dropping off or cracking

[www.lasertools.co.uk](http://www.lasertools.co.uk)