


Injector Tube Seal Installation Tool

Designed to quickly and easily replace the injector tube seals found on the DV6 1.6L 16v diesel engines that are used across the Citroën, Fiat, Ford, Mazda, Peugeot, Suzuki and Volvo ranges.



Additional Information

- Engine codes include: PSA DV6; Ford G8DX, HHDX and HHJX; Mazda Y6; Suzuki 9HX and Volvo D164T.
- Used to replace injector tube oil seals. The seal guide ensures the inner lip of the seal is guided on to the injector tube without damage.
- Hand operated press tool ensures the seal is fitted square and flush to the tube top.
- Laser also recommend the use of Part No. 6101 (Diesel Injector Seat Cleaner Set).
-

<http://lasertools.co.uk/product/7326>



