

Injector Extractor - for Bosch

Injector extractor for use on Bosch Solenoid style common rail injectors.



Additional Information

- Designed to mount directly onto the top of the injector using a 3mm Hex Key (available separately).
- Allows the injector to be removed without removing the injector's solenoid.
- Use with a slide hammer with an 5/8" UNF thread. See Laser part no. 5850 for 2.2kg (5lb) slide hammer or part no. 4811 for 4.4kg (10lb) slide hammer.
- For difficult access where an angled approach is required, please see additional adaptor Laser part no. 6123.
-

<http://lasertools.co.uk/product/7802>

Video available: <https://youtu.be/dJnqkumdRFE>



