
LASER®

Assembly Instructions



Quantity
1
2
8
8
5
4
1

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: +44 (0) 1926 818186. Normal wear and tear are excluded as are consumable items and abuse.

www.lasertools.co.uk



Distributed by The Tool Connection Ltd

Kineton Road, Southam, Warwickshire CV47 0DR T+44 (0) 1926 815000 F+44 (0) 1926 815888 info@toolconnection.co.uk