
## LASER®

## **ASSEMBLY INSTRUCTIONS**

- Unpack the product and check that no parts are missing.
- Take the base (8) and fix 2x wheels with brakes (A) using 8x screws (C), then fix 2x wheels (B) using 8x screws (C).
- Take the 2x halves of the column (5 and 6) and fix them together using 4x screws
  (C) and 4x screw nuts (D), then fix them to the base (8) using 12x screws (C).
- Take the plate (7) and fix it on the column using 12x screw nuts (D).
- Fix 4x screws (C) on the punched working table (1) then position it on the plate (7).
- Take the flanks (4, 3, 2) and connect them by using 6x screw nuts (D), then fix them on the plate using 10x screws (C).
- Fix 2x sub-plates (E) to the front flank (2) with 20x screw nuts (D).
- Finally install the drawer (9).



A	В	С	D	E
D100	D100	M6 x 12	M6	N11 230 x 230
x2	x2	x46	x42	x2