

LASER®

Motion Sensor Headlight / Work Light - Rechargeable



Dual Switches:
Power switch & Sensor switch



90° lighting angle



Charging and battery indicator



Separate mini worklight
with magnet

SPECIFICATIONS:

Dimensions	7.5 x 5 x 4.4cm
Material	ABS+TPR
Battery	3.7V 1000mAh Polymer battery included
Light Source	1pc COB +3pcs SMD LEDs
Switch	Dual Switch
Accessory	50cm USB cable

OPERATING INSTRUCTIONS:

- To turn on the light press the dual buttons on the top of the unit (fig.1)
- Dual Buttons:
Power button: Battery Indicator ON - COB ON - COB+SMD ON
Sensor button: COB and SMD SENSOR ON/OFF

CHARGING:

- Insert one head of the micro USB cable into the charging jack on the bottom of the light and the other head into the 5V 1A charging plug (Only micro USB cable included in package, no AC & DC chargers) or other moving power like power bank.
- It takes about 2-4 hours for the light to be fully charged.
- The blue LED indicator light will illuminate to indicate that the light is charging or fully charged.

HOW TO SLIP HEADLIGHT INTO MINI WORKLIGHT:

Twist off operation:

- Rotate the headlight as below correct direction
- Pull out the headlight, then headlight can be separated and used as mini worklight with strong magnet on backside.



SAFETY:

Familiarise yourself with this product's application and limitations, as well as any specific potential hazards peculiar to the headlight

DO NOT use the headlight for any purpose other than for which it is designed

DO NOT allow children to operate the headlight

DO NOT turn on while charging, could cause battery damage

DO NOT use in water or wet conditions.

DO NOT over charge the unit

DO NOT shine directly into eyes, may cause eye damaged.

MAINTENANCE:

To clean, wipe with a damp cloth

DO NOT use harsh detergents

DO NOT attempt to change LED or battery



Manufacturer: The Tool Connection Ltd
EU Authorised Representative: Comply Express Unipessoal Limitada, StartUp
Madeira, EV141, Campus da Penteada, 9020 105 Funchal, Portugal

