

## Piston Ring Installer/Remover

Spring loaded piston ring tool, for simple removal and installation of piston rings.



## **Additional Information**

- For piston rings size range 1.2 6.3mm (3/64" 1/4").
- · Length: 170mm.
- · Helps prevent ring breakage.
- · Spring loaded handles.
- · Manufactured from low carbon steel with PVC dipped grips.

http://lasertools.co.uk/product/5250









