

Brake Disc Lip Removal Tool

Brake disc lip removal tool kit, for removal of the corrosion and ridge that builds up on brakes discs and hubs.



Additional Information

- An easy to use kit for the removal of the corrosion and lip that builds up on brakes discs and hubs. Extremely useful to remove the metallic lip around the edge of the disc.
- Comprises a handle, scraper and tool steel blade.
- The handle simply bolts onto the wheel hub. Turn whilst holding the scraper against the brake disc to "machine" off rust and corrosion.
- By unscrewing the handle on the scraper, the head jaws are released and the blade can be either replaced, rotated or stored within the head for additional protection.
- Due to the nature of the application, this item is considered consumable. Spares available: Replacement blade (Part No. 7840), turning handle (Part No. 60033), scraper tool with blade (Part No. 60034), scraper tool without blade (Part No. 60035). Small brake disc lip removal tool is also available, please see Part No. 8515.

<http://lasertools.co.uk/product/7839>

Video available: <https://youtu.be/OaeytCCmHEA>

