


## Sensor Ring Installer Adaptor - for use with 8353

The Laser 8353 seal fitting tool for JLR requires a precisely manufactured spacer ring for use on certain JLR engines listed below. JLR specify this ring for use with their version of our 8353 (JLR-303-1237). Its primary function is to push the seal in a measured distance to ensure that the trigger wheel operates correctly.



### Additional Information

- Applications include: Range Rover & Range Rover Sport TDV8 3.6 & 4.4L.
- Use with Laser Part No. 8353 (OEM JLR-303-1237).
- Equivalent to OEM JLR-303-1237-01.
- Developed to be used with the OEM crankshaft position sensor ring installer to effectively reposition the sensor ring.
- Use in accordance with OEM instructions. Made in Sheffield.

<http://lasertools.co.uk/product/9377>