


Part No. 7461

LASER[®]

Truck Cabin Shock Absorber Spring Compressor

Instructions



www.lasertools.co.uk

Introduction

Many modern heavy goods vehicles and trucks have driver's cabins that have shock absorbers and springs fitted between the cabin and the chassis. Just like any shock absorber and coil spring combination these units will wear over time.


Given the dimensional size and strength of the spring used a suitable spring compressor is required to allow the spring to be compressed so the shock absorber can be replaced.

This tool has been introduced specifically to safely compress and hold the coil spring prior to removal of the shock absorber.

NOTE: to remove the top fixing on the shock absorber use Laser 6792.

WARNING: Lubricate the compressor force screw with Molybdenum Disulphide grease before use.

Components



Ref.	Description
A	Compressor
B	Torque Reaction Bar





Instructions

The following instructions are for guidance only. Please refer to OEM derived data such as the vehicles manufacturers own data.

The use of this Cabin Shock Absorber Spring Compressor tool is purely down to the user's discretion and The Tool Connection Ltd cannot be held responsible for any damage caused what so ever.

Instructions

NOTE: Ensure the cab weight is supported before removal of the spring and shock absorber.



WARNING: Lubricate the compressor force screw with Molybdenum Disulphide grease before use.



**FOR HAND TOOL USE ONLY – DO NOT USE WITH POWER TOOLS
DO NOT EXCEED 80NM TORQUE**



Safety First. Be Protected.

Our products are designed to be used correctly and with care for the purpose for which they are intended. No liability is accepted by the Tool Connection for incorrect use of any of our products, and the Tool Connection cannot be held responsible for any damage to personnel, property or equipment when using the tools. Incorrect use will also invalidate the warranty.

If applicable, the applications database and any instructional information provided has been designed to offer general guidance for a particular tool's use and while all attention is given to the accuracy of the data no project should be attempted without referring first to the manufacturer's technical documentation (workshop or instruction manual) or the use of a recognised authority such as Autodata.

It is our policy to continually improve our products and thus we reserve the right to alter specifications and components without prior notice. It is the responsibility of the user to ensure the suitability of the tools and information prior to their use.



7461_Instructions_V5



When you have finished with
this product please recycle it

www.lasertools.co.uk



Distributed by The Tool Connection Ltd

Kineton Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.

www.lasertools.co.uk