

Our products are designed to be used correctly and with care for the purpose for which they are intended. No liability is accepted by the Tool Connection for incorrect use of any of our products, and the Tool Connection cannot be held responsible for any damage to personnel, property or equipment when using the tools. Incorrect use will also invalidate the warranty.

If applicable, the applications database and any instructional information provided has been designed to offer general guidance for a particular tool's use and while all attention is given to the accuracy of the data no project should be attempted without referring first to the manufacturer's technical documentation (workshop or instruction manual) or the use of a recognised authority such as Autodata.

It is our policy to continually improve our products and thus we reserve the right to alter specifications and components without prior notice. It is the responsibility of the user to ensure the suitability of the tools and information prior to their use.



Safety First. Be Protected.

7511_Instructions_V1

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.



Distributed by The Tool Connection Ltd

Kineton Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815886
info@toolconnection.co.uk www.toolconnection.co.uk



LASER[®]

7511

Flywheel Locking Tool Multi Application



MADE IN
SHEFFIELD



**EU REGISTERED
DESIGN**


www.lasertools.co.uk

www.lasertools.co.uk

Description

Unique in its design and simplicity, the 7511 tool is designed to allow the user to quickly and simply lock the flywheel via the ring gear when removing the clutch, flywheel or front pulleys during engine strip down or clutch replacement. The 7511 can also be used to lock the ring gear when checking the dual mass flywheel play.


Components



Code	Description
A	Flywheel/Ring gear Locking Tool
B	Top hat washer (use with F)
C	2mm spacer (use with F or G)
D	5mm spacer (use with F or G)
E	8mm spacer (use with F or G)
F	M10 Bolt
G	M12 Bolt


The following instructions are for guidance only. Please refer to OEM derived data such as the vehicles manufactures own data or Autodata.

The use of this Flywheel Locking Tool is purely down to the user's discretion and Tool Connection Ltd. cannot be held responsible for any damage caused what so ever.



Instructions

Select appropriate fixing bolt (or use vehicles own bell housing bolt) and washer combination to allow the locking tool to be positioned so at least one tooth can engage fully with the flywheel as shown.



Mount the tool according to direction of torque as shown.

