


Part No. 9015

LASER®

Balance Shaft Alignment Tool

for PSA EB2

Instructions



www.lasertools.co.uk

Introduction


Designed to bolt in place of the engine side cover and align the balance shaft on the EB2 range of 1.2L petrol engines, used across the Stellantis/PSA brands.

- Applications include: various vehicles across the Citroën, DS, Peugeot & Vauxhall/Opel ranges.
- Engine code applications include: EB2 engines (1.2L) - please see website for full applications list.
- Equivalent to OEM refs. C-0109-4-BZ & EN-52128.

Use in accordance with OEM instructions.

For engine timing tools see Laser Part Nos. 6200, 8352 & 8570.

Components



Ref.	Comp. Code	OEM Ref.	Description
A	C1075	C-0109-4-BZ, EN-52128	Balance Shaft Setting Plate
B			2x Spacers

The following instructions are for guidance only. Please refer to OEM derived data such as the vehicle manufacturers' own data or Autodata.
The use of this tool is purely down to the user's discretion and The Tool Connection Ltd. cannot be held responsible for any damage caused whatsoever.



Instructions

Initial setup: Align the engine as for checking timing. Laser recommends camshaft and crankshaft timing tools are fitted – see Laser timing tool kits - Part Nos. 8570, 8352 or 6200.

Assemble the locking tool as shown as shown in figure 1 & 2. There are 2 styles of engine casing. Early engine casings do not require the spacers (B).

FIG:1





FIG:2



N.B. Observe manufacturers tightening sequence and torques for the front cover bolts.

Safety Warnings - please read

- Wear eye and hand protection when using this tool kit.
- Always carefully clean the tool components after each use.
- Keep the tool components safe and tidy in the supplied case.
- Do not use the kit for any purpose other than for which it is designed.



Safety First. Be Protected.

Our products are designed to be used correctly and with care for the purpose for which they are intended. No liability is accepted by the Tool Connection for incorrect use of any of our products, and the Tool Connection cannot be held responsible for any damage to personnel, property or equipment when using the tools. Incorrect use will also invalidate the warranty.

If applicable, the applications database and any instructional information provided has been designed to offer general guidance for a particular tool's use and while all attention is given to the accuracy of the data no project should be attempted without referring first to the manufacturer's technical documentation (workshop or instruction manual) or the use of a recognised authority such as Autodata.

It is our policy to continually improve our products and thus we reserve the right to alter specifications and components without prior notice. It is the responsibility of the user to ensure the suitability of the tools and information prior to their use.



5 018341 090159 >

9015_Instructions_V1



When you have finished with this tool please recycle it

www.lasertools.co.uk



Distributed by The Tool Connection Ltd
Kington Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.

www.lasertools.co.uk