

Part No. 4807

# LASER<sup>®</sup>

## **Oil Gauge/Dipstick**

For Audi



[www.lasertools.co.uk](http://www.lasertools.co.uk)

## Introduction

This oil gauge and dipstick is designed for measuring the oil levels on different Audi engines fitted with electronic oil level systems.

- Applications: checking oil levels on Audi 2.0 TFSI, 3.2 FSI, 3.0 Supercharged, 4.3 FSI & 2.0 TDI CR.
- Equivalent to OEM T40178.
- Also useful to assist the calibration of the driver's instrument panel.

## How To Use

Precautions and Preparation:

- Ensure the vehicle is on level ground.
- The oil must be up to a minimum temperature of 60° C/140° F.
- Switch off engine and wait 5 minutes for oil level to settle.

## Setting The Tool

1. Set the adjustable ring to the measurement shown below for the vehicle list below and tighten the lock.
2. This sets the length of the dipstick to the engine.
3. Insert the tool into the dip stick tube provided on the vehicle until the adjustable ring touches the top of the tube.
4. Remove the dipstick and read off the level on the lower scale.

## Instructions

Year	Engine Type	Ring Setting	Lower Scale Minimum	Lower Scale Maximum
From 2009	2.0 TFSi	39	0	24
From 2009	3.2 FSi	123	0	13
From 2009	3.0 Super-charged	123	0	13
From 2009	4.2 FSi	175	0	23
From 2009	2.0 TDi CR	46	0	24



[www.lasertools.co.uk](http://www.lasertools.co.uk)

Our products are designed to be used correctly and with care for the purpose for which they are intended. No liability is accepted by the Tool Connection for incorrect use of any of our products, and the Tool Connection cannot be held responsible for any damage to personnel, property or equipment when using the tools. Incorrect use will also invalidate the warranty.

If applicable, the applications database and any instructional information provided has been designed to offer general guidance for a particular tool's use and while all attention is given to the accuracy of the data no project should be attempted without referring first to the manufacturer's technical documentation (workshop or instruction manual) or the use of a recognised authority such as Autodata.

It is our policy to continually improve our products and thus we reserve the right to alter specifications and components without prior notice. It is the responsibility of the user to ensure the suitability of the tools and information prior to their use.



4807\_Instructions\_v2



When you have finished with this leaflet please recycle it

[www.lasertools.co.uk](http://www.lasertools.co.uk)



Distributed by The Tool Connection Ltd

Kineton Road, Southam, Warwickshire CV47 0DR

T +44 (0) 1926 815000 F +44 (0) 1926 815888

info@toolconnection.co.uk [www.toolconnection.co.uk](http://www.toolconnection.co.uk)

## Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.

[www.lasertools.co.uk](http://www.lasertools.co.uk)